## **HYDROLOC™ WS**

7 FLUID APPLIED | Membrane Waterproofing



#### DESCRIPTION

HydroLoc<sup>™</sup> WS is a ready-to-use, non-solvent silicone based water repellent for concrete, GFRC, and most masonry and stucco Surfaces. HydroLoc WS helps masonry resist cracking, staining, spalling and other types of damage from water intrusion. HydroLoc WS will not impair the breathing capabilities of the treated surface. HydroLoc WS has virtually no odor, and is alkaline stable.

#### **PREPARATION**

Thoroughly clean the surface using the appropriate cleaning product. Clean newly constructed surfaces before application. HydroLoc WS will not impair the adhesion of most sealing and caulking compounds. Always test for the compatibility. Protect vehicles, property, plants, windows and all non masonry surfaces from splash, residue, fumes and wind drift.

HydroLoc WS can be applied to slightly damp surfaces, however, best performance is achieved on clean, visibly dry and absorbent surfaces. Excessive moisture inhibits penetration, reducing the effective life and performance.

Use Masking tape to protect windows from overspray. Do not use in windy conditions. If HydroLoc WS gets on windows, use soap and warm water to clean windows after the HydroLoc WS has dried.

Do not use HydroLoc WS if the temperature is below  $40^{\circ}$ F (4.4° C) or above  $95^{\circ}$ F (35° C).

#### **APPLICATION**

Always test each type of surface in an inconspicuous place to determine suitability. Do Not Dilute HydroLoc WS.

**Vertical Applications** - Either use a Sprayer, Brush or Roller and saturate from the bottom up. Apply liberally and let soak in for 10 minutes. Brush out heavy runs and drips that don't penetrate. Re-saturate a second time, less HydroLoc WS will be needed for the second application.

**Horizontal Applications** - Saturate in a single application. Use enough to keep the surface wet for 2-3 minutes before penetration. Broom out puddles until they soak in.

**Paint Adhesion** - Paint may not stick to treated surfaces. Adhesion can be improved by pressure washing treated surfaces. Some cementitious coatings, plaster, stucco, etc., may not adhere well to treated surfaces. Install them first and let them thoroughly cure before applying HydroLoc WS.

#### **CLEAN UP**

Clean up tools with warm soapy water.

### **CAUTIONS**

May cause eye and skin irritation. For use by professional applicators only. Keep out of reach of children.

# **HYDROLOC™ WS**



7 FLUID APPLIED | Membrane Waterproofing

COVERAGE HydroLoc WS is recommended for these substrates			
Substrate	Туре	Coverage	
Concrete	Brick Tile Precast Panels Cast-in-place Pavers	150-200 sq. ft.	
Fired Clay	Tile Brick Pavers Terra Cotta	100-175 sq. ft.	
Sandstone	Unpolished	75-125 sq. ft.	

May help to contribute to LEED® credits:		
EA Credit 1:	Optimize Energy Performance	
EQ Credit 3.1:	Construction IAQ Management Plan: During Construction	
EQ Credit 4.2:	Low Emitting Materials: Paints and Coatings	
MR Credit 5.1:	Regional Materials: 10% Extracted, Processed and Manufactured Regionally	
MR Credit 5.2:	Regional Materials: 20% Extracted, Processed and Manufactured Regionally	

TECHNICAL SERVICES   PRODUCT SPECIFICATIONS  Type: Polymer modified asphalt waterproofing membrane		
Color	milky, white	
Active Content	8% (wt %)	
<b>Density</b> @ 75° F (23.8° C)	0.995 (g/cm <sup>3</sup> )	
pH, Approximate	> 1,000%	
Flash Point	NA	
Freeze Point	95 cPs- Typical	
Water Penetration ASTM E 514	98%	
Reduction of Water Absorption ASTM C 140	90%	
Surface Discoloration	None	
Penetration (Depending on surface)	1-10 mm	
Resistance to Sunlight	Excellent	
Resistance to Alkalinity	Excellent	
Surface Appearance	No Change	

**CAUTION:** KEEP FROM FREEZING DURING TRANSIT AND STORAGE.





GMX, Inc. 3014 Chamber Dr. Monroe, NC 28110 Toll Free: 866-228-7743 www.gmxwaterproofing.com